

# How-To Ceramic Spray Wax

## **BEFORE GETTING STARTED:**

Make sure you aren't spraying in high humidity, direct sunlight, rain, wind or any source of contaminants. Do not apply the product on hot surfaces. Don't forget to check out our How-to Ceramic Spray Wax video before using the product.

## **ONLY APPLY ON:**

Painted body panels, Headlights, Windshields, Wheels and Carbon Fiber surfaces.

## **Step 1: Preparation**

1. Thoroughly wash and rinse the surface to remove loose dirt and debris.
2. Use the LiquidShield Prep Wipe to remove any surface oils, contaminants or residue.
3. Dry the surface using a clean microfiber cloth.

## **Step 2: Application**

4. Working one panel at a time, spray a thin and even coat on the surface.
5. Wait 1-2 minutes and buff the surface using a clean microfiber cloth.
6. Allow 4 hours to cure before exposing your surface to elements (sun, rain, etc.).