

How-To Maintain

CHECK OUT OUR SUPERWRAP LABS MAINTENANCE EPISODE
HERE: https://youtu.be/mjMYiXpm_mY

What you will need:

- Microfiber Cloth. Buy it [here](#)
- Superwrap Wheel Cleaner (optional). Buy it [here](#)

Instructions

1. Read the back of the label for instructions.
2. Rinse the surface
3. Apply wheel cleaner on the surface and let it sit for 1 minute
4. Rinse the Wheel Cleaner or Cleaning Product with water
5. Wipe it clean with a microfiber cloth

* We do not recommend going through automatic car washes. Many customers have gone through touch-less traditional car washes without any issues, however given there is no general standardization for pressure, soaps and waxes used, we suggest caring for your LiquidShield surface yourself with Superwrap Wheel Cleaner or a non-acidic cleaner.

* LiquidShield finishes can be pressure washed as long as the coating is not torn or chipped. Excessive pressure may damage the LiquidShield paint. Do not use a narrow tip.

* LiquidShield requires adequate curing time before driving and washing your car. We recommend waiting at least 12 hours before driving and at least 5 days before washing the sprayed surface to allow for a complete curing process.

* Stay away from abrasive or high acid products to clean your LiquidShield surface. Use any low acid or Superwrap Wheel cleaner.

* Avoid households products (dawn, windex, etc.)